

House rules







For entering and driving on the premises of Neuss Trimodal GmbH, Tilsiter Straße 15, 41460 Neuss.

<p>1. Instructions of the terminal staff must always be followed. It is strictly forbidden for unauthorised persons to enter the terminal.</p>	
<p>2. High-visibility clothing and helmets must be worn on the terminal.</p>	
<p>3. Before driving onto the terminal to drop down or pick up a cargo unit, it is necessary to register at the Gate-In office. It is not permitted to enter/drive onto the terminal site without authorisation. Visitors or external companies must register with the terminal management or the control centre and acknowledge receipt of the security conditions before entering the terminal premises.</p>	
<p>4. Entering railway tracks and storage facilities outside the marked ways. Climbing onto loading units and climbing onto or crawling under railway vehicles is strictly forbidden in the whole terminal area.</p>	
<p>5. The German Road Traffic Regulations (Straßenverkehrsordnung = StVO) and the authorised maximum speed of 25 km/h apply throughout the terminal. However, the driving speed must always be adapted to visibility and traffic situation. The engine must be turned off during waiting times.</p>	
<p>6. Overtaking anywhere in the terminal is absolutely forbidden. Exceptions can only be authorised by the terminal staff. A minimum distance of 5 metres from the next vehicle must be ensured at all times. Do not step or drive under hanging units/loads.</p>	
<p>7. Handling equipment, forklift trucks and rail vehicles have the first right of way. In addition, always keep the greatest possible distance from the handling equipment. When approaching handling equipment, always make sure that you are noticed by the equipment operator. Furthermore, the "blind spot" (restricted visibility) must be respected. Before passing a handling device, make sure that you have been noticed by making visual contact with the device operator. You are only permitted to pass or drive past the handling equipment once you have received a recognisable confirmation from the equipment operator. It is strictly forbidden to walk behind the handling equipment.</p>	
<p>8. The unauthorised parking and repair of vehicles is strictly prohibited on the terminal-area.</p>	
<p>9. Prepare for loading and unloading by the lorry driver:</p> <ul style="list-style-type: none"> • During the loading or unloading process, leave the driver's cab and keep visual contact with the equipment operator at all times. • The proper unlocking/locking, the proper connection of the loading unit to/from the truck in particular the loosening/tightening of the fastening devices including their securing device and their further preparation for driving on the road (e.g. changing the support legs as well as the side and rear underride guard) must be carried out by the driver collecting the vehicle on his own responsibility. • The twist locks must only be released immediately before unloading or locked immediately after the loading unit has been positioned. • Loosen the air hoses on semi-trailers. • When picking up loading units from empty container stacks, remove the connectors (container fuses) and hand them over to the equipment operator. 	

House rules



<ul style="list-style-type: none"> The readiness to crane the unit must be announced to the equipment operator using the adjacent hand signal. <p>If waiting times occur, these must be bridged outside the driver's cab. Furthermore, terminal operations must be closely monitored in order to recognise any dangerous situations that may arise at an early stage.</p>	
<p>10. The terminal is video-monitored. The video material is archived for 4 weeks and may be used by Neuss Trimodal GmbH in the event of an accident, theft protection and for any other reason.</p>	
<p>11. Smoking, fires and open flames as well as the consumption of alcoholic beverages or drugs are strictly forbidden on the entire terminal site!</p>	
<p>12. Photography and filming is not permitted anywhere on the premises. Any offence will be prosecuted.</p>	
<p>13. By entering the company premises, you accept the house rules without reservation.</p>	

Offences against these house rules can be sanctioned with a house ban!